



HF/VHF AUTOMATIC PLL SYNTHESIZED
ARDF TRANSMITTER

CONTEST 2002

instruction manual

INTRODUCTION

The first PLL synthesized fully programmable ARDF transmitter is designed for any level of ARDF competition or training. The possibility of frequency adjustment opens the new area in the ARDF competitions and allows using more transmitters on different frequencies. All parameters are widely adjustable via user-friendly menu, settings are stored in EEPROM memory.

After features are set, the operation is very easy: just install the antenna, plug in the connector and transmitter automatically recognizes the proper band and starts operation. If antenna is disconnected, the transmitter turns to the STANDBY mode (only 2 mA consumption) and after 30hours, turns off itself. The accumulator is internally protected against deep discharge and its status is indicated at the end of every relation.

For training purpose, you can use the transmitter without the external accumulator (its weight will be then less than 1 kg).

Rugged, waterproof aluminum house protects the transmitter against the environmental influences, anti-theft loop with cable lock protects it against stealing.

IMPORTANT!

Read this instruction manual carefully before attempting to operate the transmitter.

Save this instruction manual. This instruction manual contains important safety and operating instructions for the CONTEST2002.

PRECAUTIONS

! NEVER apply AC or more than 16V DC to any socket of the transmitter. This may cause fire or ruin the transmitter.

! NEVER use any charger except for the one supplied by the manufacturer. You may ruin the accumulator or even the whole transmitter.

AVOID using or placing the transmitter in the areas with temperatures below -20°C or above +60°C.

Use only accessories supplied by the manufacturer..

TABLE OF CONTENTS

INTRODUCTION	4	PARAMETER SETTING
IMPORTANT	■	General
PRECAUTIONS	■	Code and keying speed
TABLE OF CONTENTS	■	Timing schedule
UNPACKING	■	Frequency
	■	Power
1 PANEL DESCRIPTION		5 MAINTENANCE
■ Top panel		■ Fuse replacement
■ Front panel		■ Charging
■ Front panel display		■ Cleaning
2 INSTALLATION		6 TROUBLESHOOTING
■ Unpacking		
■ Before operating		7 SPECIFICATIONS
■ Switching on		
■ MODE selector		8 TECHNICAL INFORMATION
■ Clock synchronizing		
■ 3,5 MHz antenna installation		9 OPTIONS
■ 144 MHz antenna installation		
■ Switching off		10 WARRANTY, SERVICE
3 OTHER FEATURES		
■ Supply		
■ External accumulator		
■ Band selecting		


UNPACKING

Accessories included with the CONTEST2002:


- antenna and counterpoise for 3,5 MHz band
- antenna and 2+2 elements for 144 MHz band
- external accumulator 12V/2,6 Ah.
- carrying case
- fuse F4A (2 pcs)
- this manual

1 PANEL DESCRIPTION


■ Top panel:



■ Front panel:



■ Front panel display:



2 INSTALLATION

■ Unpacking

After unpacking, check carefully the transmitter and all accessories included. In the case of any damage do not use the transmitter and contact immediately the manufacturer.

■ Before operating

Before the first usage, charge the accumulator for 24 hours. Please, use this time for reading of this instruction manual.

■ Turning the transmitter ON:



Push the START button on the front panel. Clock and basic setting information will appear on the display and the green LED will flash on the top panel.

■ MODE selector

Selector has four positions:

- **SET** (setting) - enables settings change and transmitter shutdown.
- **STBY** (standby) - transmitter does not transmit, only logic unit is running.
Transmitter enters this state automatically also when no antenna is connected or accumulator is discharged.
- **REL** (relations) - transmitter operates in relations according to the settings and antenna connected.
- **CONT** (continuously) - transmitter operates continuously according to the settings and antenna connected.

■ Time base synchronization

• One transmitter starting

Turn on the transmitter exactly at the beginning of the 1st minute of the cycle.

• Starting the set of transmitters by means of a synchronocable

1. Turn on all transmitters (see above).
2. Connect grey connectors of the synchronocable to the sockets on top panels.
3. Exactly at the beginning of the 1st minute of the cycle push the button START on the synchronocable.
4. Disconnect the synchronocable from all transmitters.

• Running transmitter restart

Exactly at the beginning of the first minute push the RESET button on the front panel (by means of ballpoint pen, for example). The rest of the controls may remain unchanged, the transmitter will keep operation as before, only the clock are restarted.

■ 3,5 MHz antenna installation

3,5 MHz antenna consists of a counterpoise (the wire ended by a DIN connector) and the radiator itself (the wire ended by a banana plug).

Lay the counterpoise wire on the ground, straight towards the competition starting point. In case of the 3-radial counterpoise, lay the radials to all directions.

The radiator shall hang, for instance, from the tree branch. Use the whole length of the radiator if possible. During dry weather, the radiator may lay even on the tree trunk surface. During rain, when the trees are wet, the radiator shall better hang in a free space.

Plug the banana plug into the socket at the counterpoise wire and the DIN connector to the socket on the top panel of the transmitter.

Avoid close vicinity of large metal objects such as fences, rails or wires, which disturb the electromagnetic field and makes the finding difficult.

NOTE: It is advisable to turn the counterpoise once around the tree in order to prevent the plugs against whipping out when the competitor catches the counterpoise wire.

■ Antenna tuning


Turn the **MODE** selector to the **CONT** position, then tune the antenna by the **ANT** button. Try to reach the maximum brightness of the indicator. Then eventually turn to the **REL** position. Do not touch the transmitter house while tuning.

■ 144 MHz antenna installation

The 144 MHz antenna consists of an antenna body with cable and four elements (two short and two long). Screw the elements into the antenna body - the shorter ones horizontally and the longer tilted. Hang the antenna on the tree branch by the string tied on the top of an antenna body. The coax cable shall lead vertically down.

Install the antenna as high as possible, 3 m at least. Plug the DIN connector to the socket on the top panel. The 144 MHz antenna needs no tuning. The ANT indicator shows only transmitted carrier.

■ Turning the transmitter OFF:



1. manually: in the basic menu status (clock on the display) push the **ENTER** button, then push **UP** and **DOWN** buttons simultaneously.
2. automatically - transmitter will automatically turn off itself 30 hours after the last start or reset.

3 OTHER FEATURES

■ Supply:

The transmitter is supplied by the built-in sealed lead 12V accumulator. As this accumulator is sensitive to the deep discharge, there is two stage protection and telemetric signalisation provided.

Under normal conditions (transmitter running, accumulator charged) there is green indicator flashing on the top panel. If the transmitter operates in relations, every relation ends with a long dash showing the normal accumulator voltage. No dash found at the end of the relation means that the accumulator is exhausted and within next 10 to 30 minutes (according to the power and band) internal protection will disable the transmitter in order to prevent the accumulator from deep discharge. The transmitter referee could be warned in advance in order to use spare transmitter or external supply.

If the accumulator voltage sinks under 10,3V, the indicator on top panel goes out and the transmitter turns to the STBY mode (see above). After normal accumulator voltage recovers (by connecting the external accumulator, for example), the transmitter continues in normal operation.

■ External accumulator

Using the external accumulator will extend the operating period four times. Put the accumulator to the back carrying case compartment and connect it to the socket on the top panel. External accumulator is charged through the transmitter.

■ Band selecting:

The transmitter recognizes connected antenna and selects automatically the appropriate band. If no antenna is connected, the transmitter turns to the STBY mode (regardless of the **MODE** selector position).

4 SETTINGS


■ General:

Any setting can be changed (or transmitter turned off) only with the **MODE** selector in the **SET** position. In other positions, the menu items can be browsed and read only.

Settings change: select the wanted menu part by the **UP/DOWN** buttons, then push **ENTER**. Parameter menu will appear, current value flashes and can be changed by the **UP/DOWN** buttons. Confirm the chosen value by **ENTER**, which possibly moves you to the next menu item.

Settings are stored in non-volatile memory and remain there until they are again user-changed.

■ Code and keying speed setting:




Code setting possibilities: MOE, MOI, MOS, MOH, MO5, MO, A...Z.

Keying speed setting possibilities: 35, 50, 70, 100 PARIS.

Setting the code MOE ... MO5 automatically adjusts the relation position in cycle (see also below).

■ Timing schedule setting:




Timing schedule setting possibilities:

60/240:	60 s transmitting, 240 s space
30/120:	30 s transmitting, 120 s space
30/270:	30 s transmitting, 270 s space
12/48:	12 s transmitting, 48 s space
15/45:	15 s transmitting, 45 s space
30/30:	30 s transmitting, 30 s space
15/15:	15 s transmitting, 15 s space

The beginning of the relation can be shifted by any multiple of the relation length along the whole 5-minute cycle. The MOE, MO, A ... Z codes have the default setting +0, it means that the relation begins at the beginning of the cycle. The MOI ... MO5 codes are on default adequately shifted in the cycle. This offset can be, however, manually changed to any desired value. Resetting the code will reset also the relation offset to the default.

■ Frequency setting:




Možnosti nastavení kmitočtu v pásmu 80m:

3,52 MHz	3,57 MHz	3,62 MHz	3,67 MHz
3,53 MHz	3,58 MHz	3,63 MHz	
3,54 MHz	3,59 MHz	3,64 MHz	
3,55 MHz	3,60 MHz	3,65 MHz	
3,56 MHz	3,61 MHz	3,66 MHz	

Možnosti nastavení kmitočtu v pásmu 2m:

144,50 MHz	144,67 MHz	145,20 MHz
144,55 MHz	144,75 MHz	145,33 MHz
144,60 MHz	144,85 MHz	145,50 MHz

■ Power setting:



Úroveň výkonu VYSOKÝ odpovídá přibližně výkonu 3W v pásmu 3,5 MHz a 3W PEP v pásmu 144 MHz, úroveň výkonu NÍZKÝ odpovídá výkonu 0,9W v pásmu 3,5 MHz a 0,7 W PEP v pásmu 144 MHz.


5 MAINTENANCE

■ Fuse replacement:

Either built-in or external accumulators are protected against shortcontact by the fuses o5x20mm, F4A. Replace the blown fuses with the ones of the same value only!

Procedure of fuse replacement:

1. Remove 2 screws on the sides of the bottom panel of the transmitter or external accumulator and remove the panel.
2. The fuse position is shown at the pictures:



Release the fuse holder with a screwdriver (push and turn counterclockwise) and remove it. Replace the blown fuse, put the holder back and secure it by pushing and turning clockwise.

3. Put the bottom panel back and return the screws.

■ Charging

The charging period is 1-10 hours according to the discharge level. After the accumulators are charged, the charger automatically switches to trickle charging. The transmitters may remain connected to the charger even a day or two, but not forever.

External accumulator is charged through the transmitter, being connected to the socket on the top panel.

Keep the accumulators fully charged. Charge them after every competition and also after the longer period of inactivity.

■ Cleaning:

Keep the transmitter dry and clean. If the transmitter becomes wet, dry it by the clean cloth and let it dry in a room temperature. **Never** use strong heaters! If the transmitter becomes dusty or dirty, clean it with a brush or a dry, soft cloth. **Avoid** the use of strong chemical solvents such as benzine or alcohol to clean the transmitter.

The transmitter needs no maintenance above the mentioned procedures.

6 TROUBLESHOOTING

The following list is designed to help you correct problems which are not equipment malfunctions. If you are unable to locate the cause of a problem or solve it through the use of this list, contact the manufacturer.

- **After turning on the indicator does not flash but display shows normally**
Possible cause: exhausted accumulator
Solution: recharge the accumulator immediately
- **After turning on the indicator does not flash and display is blank**
Possible cause: blown fuse
Solution: check for possible cause, then replace the fuse
- **Transmitted signal is distorted or interrupted**
Possible cause: exhausted accumulator (protection starts activating)
Solution: recharge the accumulator immediately or connect the external
- **Transmitter poorly audible (3,5 MHz)**
Possible cause: antenna not properly tuned or installed, radiator wire whipped out of the socket
Solution: check for the antenna installation and/or tuning
- **Transmitter poorly audible (144 MHz)**
Possible cause: antenna too low or tilted, element(s) lost
Solution: check for the antenna installation
- **Transmitter transmits wrong code or in wrong time**
Possible cause: wrong settings, clock start
Solution: check for the settings, restart the clock
- **Transmitter does not respond to controls, does not transmit, strange characters appear on the display**
Possible cause: microsoftware malfunction, probably in connection with the exhausted accumulator
Solution: push the **Reset** button on the front panel (with the ballpoint, for example). If it will not help, remove the fuse for a while (and disconnect the external accumulator)

7 SPECIFICATIONS

■ General

Supply	built-in sealed lead accumulator 12V/0,8Ah or external sealed lead accumulator 12V/2,6Ah		
Operating temperature range	-10...+ 60°C		
Storage temperature range	-20...+ 60°C		
Covering	IP65		

Transmitter:

Dimensions	80(W)x40(H)x195(D) mm (without projections)		
Weight	970 g		

External accumulator:

Dimensions	80(W)x40(H)x195(D) mm		
Weight	1430 g		

Operating period (hrs, 3,5-144 MHz)	REL high power		CONT low power	
	REL	CONT	REL	CONT
built-in accu only	12-17	2-3,5	22-30	4,5-6
with ext. accumulator	50-70	10-15	90-130	19-27

■ 3,5 MHz transmitter

Carrier frequency	16 channels (3,52 ... 3,67 MHz)
Mode	A1A (CW)
Output RF power @ 50 ohm	HIGH: 3 W, LOW: 0.9 W
Spurious emissions:	less than -66 dB
Antenna:	vertical wire 8 m + 8 m counterpoise

■ 144 MHz transmitter


Carrier frequency	9 channels (144,5 ... 145,5 MHz)
Mode	A2A, keyed carrier, AM 75%
Output RF power @ 50 ohm	HIGH: 3 W PEP, LOW: 0.7 W PEP
Spurious emissions:	less than -60 dB
Antenna:	omnidirectional turnstile

■ Logic unit

Transmitted codes	MOE, MOI, MOS, MOH, MO5, MO, A ... Z
Keying speed:	35,50,70 or 100 PARIS
Timing schedules:	60/240 (s, transmit/space), 30/120, 30/270, 12/48, 15/45, 30/30, 15/15
Time stability	+/-10 ppm (approx. 1 s/day)
Firmware version:	V112GB

8 TECHNICAL INFORMATION

Top panel connector pin-out:



1	144 MHz antenna
2	common ground
3	3,5 MHz antenna
4	144 MHz band enable
5	3,5 MHz band enable
6	12V accumulator
7	reset

9 OPTIONS

- Automatic charger for 1-6 transmitters
- Synchro cable
- Automatic DCF controlled synchronizer
- Foxoring whip antenna
- Various transmitting antennas
- Cable lock

10 WARRANTY, SERVICE

Should this equipment malfunction under normal use, it will be repaired without charge for a period of one year from the date of purchase.

The customer shall not have any claim under this warranty for repair or adjustment expenses if the trouble is caused by improper, rough or careless treatment or mechanical damage, by a fire or other natural calamity or by improper repair or adjustment made by anyone other than manufacturer.

The warranty does not cover the accumulators.

After the first year of use manufacturer offers the free of charge adjustment and check of the equipment including the recalibration of clock and synthesizer. Any other information, service or modifications are provided by the manufacturer:

**Jiří Mareček, OK2BWN, Obřanská 593, CZ-664 01 Bílovice nad Svitavou
phone/fax +420 545227041, e-mail: marecek@sky.cz**



Jiří Mareček, OK2BWN
CZ-664 01 Bílovice nad Svitavou, Obřanská 593
phone/fax +420 545227041, e-mail: marecek@sky.cz
<http://www.marecek.sky.cz>